

SUBMITTAL COVER SHEET

PROJECT NAME LOCATION ARCHITECT	
ENGINEER	
CONTRACTOR	DATE
UNIT	SUMMARY
Quantity	
Unit Designation	
Model No.	
Total Cooling	
Sensible Cooling	
Air Ent. Evaporator	
Air Lvg. Evaporator	
Heating Input	
Heating Output	
CFM/ESP	
EER/SEER	
Electrical	
Minimum Ampacity	
MinMax. Breaker	
Net Unit Weight	
Accessory	
Catalog Form Number	
ACCESSORIES:	NOTES:

Endeavor™ Line Cased/Uncased Coils For Gas and Oil Furnaces



RCFZ

Featuring Industry Standard R-410A Refrigerant Airflow Capacity 600-1,900 CFM [283-897 L/s]

Features & Benefits

- Rheem® Indoor Furnace cased coils and replacement uncased coils are designed for use with Rheem outdoor units and are available for vertical upflow or downflow, and horizontal left or horizontal right airflow. When matched with Rheem outdoor units, the coils provide a nominal capacity range from 18,000 BTU/HR [5.24 kW] to 60,000 BTU/HR [17.6 kW]
- Constructed of aluminum fins bonded to internally grooved aluminum tubing
- Coils are tested at the factory with an extensive refrigerant leak check
- Coils have copper sweat refrigerant connections
- Feature two sets of ³/₄" [19.1 mm] N.P.T. Condensate drain connections for ease of connection
- Chatleff metering device connections, at inlet and outlet of TXV or EEV and equalizer connections (TXV only)

Condensate drain pan is constructed of high grade, heat

outdoor units

 Condensate drain pan is constructed of high grade, heat resistant, corrosion free thermal-set material

· Approved for system application with variety of Rheem


- · Compatible with Germicidal Light System (UV resistant)
- Bi-Directional airflow eliminates the need to switch any internal components from horizontal left to right
- Unique drain pan design maximizes application flexibility and condensate removal
- N-Coil design maximizes performance and minimizes height required at installation
- Coils are AHRI certified for system application with a variety of Rheem outdoor units

[] Designates Metric Conversions

Cased Coil Dimensions and Weights

0.11	Connections I.D.		Cased Coil Dimensions			Weight	
Coil Model RCF	Sweat (in.) [mm]		(in) [mm]			Coil Weight	Shipping Weight
moust not	Liquid	Suction	A	В	C	(lbs.) [Kg.]	(lbs.) [Kg.]
2414S*	3/8 [9.53]	3/4 [19.05]	14 [356]	201/16 [535]	233/16 [584]	45 [20]	49 [22]
2417S/2517S	³ /8 [9.53]	3/4 [19.05]	17 ¹ /2 [445]	14 ¹ /2 [368]	20 [508]	43 [19]	48 [21]
2417M/3617S/3717S	³ /8 [9.53]	3/4 [19.05]	17 ¹ /2 [445]	17 [454]	20 [508]	49 [22]	54 [24]
2421M/3621S	3/8 [9.53]	3/4 [19.05]	21 [533]	17 ¹ /2 [445]	20 [508]	51 [23]	57 [25]
2421H/3621M/4821S/4921S	3/8 [9.53]	7/8 [22.23]	21 [533]	25 [657]	28 [711]	71 [32]	78 [35]
3624M/4824S	3/8 [9.53]	7/8 [22.23]	241/2 [622]	25 [645]	32 [812]	83 [38]	93 [42]
4824M/6024S/6124S	3/8 [9.53]	⁷ /8 [22.23]	241/2 [622]	301/4 [768]	32 [812]	100 [45]	110 [50]
2421H*/3621M*/4821S*/6021S*	³ /8 [9.53]	7/8 [22.23]	21 [533]	33 [838]	341/2 [876]	76 [34]	86 [37]


^{* = &}quot;A" Coil



[] Designates Metric Conversions

Accessories (Con't.)

FIGURE 2: HORIZONTAL ADAPTER KIT ILLUSTRATION



Unit Dimensions and Weights

RXBC Indoor Coil Casings

Model	Width	Height	Depth	Unit V	Veight	Supply Air/Return Air Openings		
Number	(in.) [mm]		(in.) [mm]	Weight (lbs.) [Kg.]	Ship. Wt. (lbs.) [Kg.]	Width (in.) [mm]	Depth (in.) [mm]	
RXBC-D14AI	14 [356]	233/16 [589]	21 ⁵ / ₈ [549]	19 [9]	23 [10]	13 [330]		
RXBC-D17AI	171/2 [445]	20 [508]		18 [8]	23 [10]	16 ¹ / ₂ [419]	10011	
RXBC-D21AI	21 [533]	20 [508]		20 [9]	26 [12]	20 [508]	19 ³¹ / ₃₂ [508]	
RXBC-D21BI	21 [533]	28 [711]		27 [12]	36 [17]	20 [508]	[000]	
RXBC-D24AI	241/2 [622]	321/2 [826]		34 [16]	44 [20]	231/2 [597]		

Uncased Coil Adapter Kit


Uncased Coil Adapter Model Number RXBA	A Width (in.) [mm]	Uncased Coil Model RCFP
B14x20	13 ¹ /8 [333]	(-)CFZ2414
B17x20	16 ⁵ /8 [422]	(-)CFZ**17
B21x20	201/8 [511]	(-)CFZ**21
B24x20	235/8 [599]	(-)CFZ**24

• UNCASED COIL ADAPTER KIT RXBA- (See Figure 3 & 4)

This uncased coil adapter kit is used to adapt the coil to a furnace or ductwork. See Table 6 to order the proper adapter kit. Each kit contains a quantity of 20 adapters.

FIGURE 3: UNCASED COIL ADAPTER KIT ILLUSTRATION

FIGURE 4: UNCASED COIL ADAPTER KIT ASSEMBLED



Note: Sliding the coil into the coil rail before attaching coil rack front.

[] Designates Metric Conversions