RUUD

SR-SERIES
QUICK START CONNECTION GUIDE
POWERED BY **ECONET® TECHNOLOGY**

WELCOME TO RUUD® SR-SERIES
POWERED BY ECONET® TECHNOLOGY

Experience the ultimate in continuous hot water and convenience with Ruud SR-Series Condensing Tankless Water Heaters and built-in Wi-Fi powered by EcoNet technology. When downloaded to your smart device, the free EcoNet app allows you to control your water heater while on-the-go or at home.

Set the water temperature, monitor your energy use and get real-time alerts and notifications for added peace of mind. Plus, EcoNet is compatible with Alexa® and Google Home® voice control for smart home integration.

EcoNet®

EcoNet® lets you control and monitor your Ruud® SR-Series water heater. We will guide you through the easy setup on the following pages.

SAY "HELLO" TO ECONET®

Enjoy ultimate control from home or away.

The EcoNet app let's you optimize your Ruud® SR-Series from your smartphone. Control temperature and recirculation modes. Set customized schedules to fit your busy lifestyle. Receive information alerts like maintenance reminders and track energy usage.

OVERVIEW DASHBOARD
View alert notifications, local weather and connected device status

ON DEMAND PUMP CONTROL
Turn on recirculation pump at the touch of a button

SCHEDULING
Set temperature schedule and recirculation schedule (if equipped)

ALERTS, NOTIFICATIONS AND ERROR CODE SETTINGS
Includes maintenance reminders and a scalding alert for set points above 120°F.

WATER SAVING SETTING
Reduces water flow until set temperature is reached

MONITOR ENERGY CONSUMPTION
(kBTU)

MONITOR WATER CONSUMPTION
(gallons)

AMAZON ALEXA & GOOGLE HOME INTEGRATION+ VOICE COMMANDS
See setup on pages 12 & 13

works with **alexa**

works with **Google Home**

STEP 1 DOWNLOAD THE FREE ECONET® APP

The EcoNet® App is available on Apple and Android phones.

Scan to go directly to the App Store and Google Play

Download on the **App Store**

GET IT ON **Google Play**

1 On your Apple or Android phone, **visit** the App Store or Google Play.

2 **Search** for and download the EcoNet® App.

3 **Create an** EcoNet® account

4 **Enter** account information including the water heater name and Contractor information (name, email, phone number)

STEP 2 BEGIN SETUP ON THE TANKLESS DISPLAY

Using the touchscreen digital keypad, prepare your water heater for Wi-Fi.

1 **Click** the Service button

2 • Using up or down arrows, **navigate** to "Network Instance"

• **Click** the Enter button

3 • Using up or down arrows, **navigate** to "Wi-Fi Setup"

• **Click** Enter button

• Using up or down arrows, **scroll** to "Wi-Fi Setup"

• **Click** the Enter button to begin Wi-Fi

4 The Wi-Fi symbol will start blinking

STEP 3 CONFIGURE SETTINGS

Before setup, ensure your Ruud SR-Series is set up
and operating, and the EcoNet® App is installed.

💡 **TIP** In the event of a power outage, Ruud SR-Series will automatically reconnect itself
to the Wi-Fi and the EcoNet® app when power is restored.

① **Click** the "Add
Product Button"

② **Select** the digital
control icon for
your Ruud
SR-Series
display.

③ **Press** "Continue" to begin
the connection process

④ **Connect** your
water heater to
your home Wi-Fi

⑤ **Select** your
Wi-Fi Network.

⑥ Your water heater is
now **Connected!**

AMAZON® ALEXA® INTEGRATION

Before setup, ensure your Amazon® Echo account
is set up, and the Alexa® App is installed.

💡 **TIP** To change the name of your Ruud SR-Series, go to "Devices" on your Amazon®
Alexa®. This device name will be what you reference when giving voice commands
to Alexa®. It should be different from other devices on the Alexa® account.

① On the EcoNet®
app, **press** the
Menu bar and
select "Ask Alexa."

② **Click** "Launch Alexa
App"

GOOGLE® HOME® INTEGRATION

Before setup, ensure your Amazon® Echo account
is set up, and the Alexa® App is installed.

💡 **TIP** To change the name of your
Ruud SR-Series, go to "Devices"
on your Google® Home®. This
device name will be what you
reference when giving voice
commands to Google. It should
be Google account.

① On the EcoNet®
app, **press** the
Menu bar and
select "Ask
Google Home."

② **Click** "Launch
Google Home
App"

ALEXA & GOOGLE **VOICE COMMANDS**

Adjust Temperature
- Increase "Tankless" temperature by 10 degrees
- Increase "Tankless" by 6 degrees
- Decrease "Tankless" temperature by 6 degrees
- Decrease "Tankless" by 6 degrees
- Decrease "Tankless"
- Decrease "Tankless" temperature
- Increase "Tankless"
- Increase "Tankless" temperature
- Make water warmer/cooler

Temperature Questions
- What is the "Tankless" temperature?
- Get the "Tankless" temperature

Change Power State (On/Off)
- Turn on "Tankless"
- Turn off "Tankless"
- Turn "Tankless" on
- Turn "Tankless" off
- Turn (the) "Tankless" on
- Turn (the) "Tankless" off

Change Setpoints
You may only change the setpoints when it is in Home Mode.
- Set setpoints to N degrees
- Adjust setpoints by N degrees
- Set "Tankless" temperature to 120 degrees
- Set "Tankless" to 130 degrees

Recirculation Pump Control
- Turn on recirculation on the "Tankless"
- Start recirculation on the "Tankless"

Your Ruud® super high-efficiency condensing tankless water heater is loaded with features to help you save money and reduce water waste. And these ultra low NOx tankless solutions are up to 96% efficient to reduce energy costs, too.

CONTACT US

Customer Service, Warranty and Parts
800.621.5622

Technical Service
800.HEATER3
(800.432.8373)

EcoNet® Support
800.255.2388

Plumber Support Group
866.339.2388