

SUBMITTAL COVER SHEET

PROJECT NAME									
LOCATION									
ARCHITECT									
ENGINEER CONTRACTOR									
UNIT SUMMARY									
Quantity									
Unit Designation									
Model No.									
Total Cooling									
Sensible Cooling									
Air Ent. Evaporator									
Air Lvg. Evaporator									
Heating Input									
Heating Output									
CFM/ESP									
EER/SEER									
Electrical									
Minimum Ampacity									
MinMax. Breaker									
Net Unit Weight									
Accessory									
Catalog Form Number									
ACCESSORIES:	NOTES:		·						

MODEL NO
FEATURES FOR S98V ntial gas furnace CSA certified operation to save energy and maintain optimal comfort level. eed blower motor technology provides ultimate humidity control, quiete s, and year round energy savings. 5 7-Segment LED all units tem – DSI for reliability and longevity
operation to save energy and maintain optimal comfort level. eed blower motor technology provides ultimate humidity control, quiete s, and year round energy savings. s 7-Segment LED all units tem – DSI for reliability and longevity
agement System with patented Blocked Drain Sensor siency – Industry's highest A.F.U.E. Gas Furnace family. The S98V % A.F.U.E. across all model sizes nger is removable for improved serviceability. Aluminized steel primary is steel secondary construction provide maximum corrosion resistance I fatigue reliability. "34 inch" cabinet ideal for space constrained installations. If design – serviceable in all furnace orientations hoses – insures proper system drainage " or 3" PVC e collector box dges on cabinet and doors n door fasteners for tool less access control boards feature dip switches for easy system set up g condensate trap m included Function: when used with a two-stage thermostat, furnace operates at t stage, and stages up to 65%, then 100% for second stage. Function: when used with a single-stage thermostat, furnace functions stage furnace operating at 40%, 65% and 100% of total capacity.
FIELD INSTALLED ACCESSORIES on Kits Concentric: lorizontal = RXGY-E03A-E02A (US & Canadian ns)
a sign rist " e din o gin Ent Estan o lor sign e filler

Г



UNIT DIMENSIONS (CLEARANCE TO COMBUSTIBLES)

MODEL (-)98V	LEFT SIDE	MINIMUM CLEARANCE (IN.) [mm]				FLANGE DIMENSIONS				
		RIGHT SIDE	BACK	ТОР	FRONT	VENT	(LBS.) [kg]	A	В	C
060	0	0	0	1 [25]	2 [51]	0	128 [58]	171/2 [445]	16 ¹⁷ /64 [413]	16 ¹³ /64 [412]
070	0	0	0	1 [25]	2 [51]	0	132 [60]	17 ¹ /2 [445]	16 ¹⁷ /64 [413]	16 ¹³ /64 [412]
085	0	0	0	1 [25]	2 [51]	0	147.5 [67]	21 [533]	19 ⁴⁹ /64 [502]	19 ⁴⁵ /64 [500]
100	0	0	0	1 [25]	2 [51]	0	152 [69]	21 [533]	19 ⁴⁹ /64 [502]	19 ⁴⁵ /64 [500]
115	0	0	0	1 [25]	2 [51]	0	165 [75]	241/2 [622]	23 ¹⁷ /64 [591]	23 ¹³ /64 [589]

*A service clearance of at least 24" is recommended in front of all furnaces

Supply and return depicted as upflow configuration.

 $\label{eq:Flange configuration will vary depending on installation orientation.$

[] Designates Metric Conversions



Russell[™] By Rheem 5600 Old Greenwood Road, Fort Smith, AR 72908 Before proceeding with installation, refer to installation instructions packaged with each model, as well as complying with all Federal, State, Provincial, and Local codes, regulations, and practices.

PRINTED IN U.S.A. 6/21 QG FORM NO. XRR-1573